

Comprehensive Operating Manual

The company reserves the right of making changes to the product. If there is any change to the product, forgive us for not giving notice. Product appearance depends on goods.

Please take care of the instructions, warranty card and the widgets. Some of widgets are small, but with great importance. Remember to keep them well. Since the operating manual is comprehensive, If you are troubled by some specific usage, we would like to apologize.

Warning: 1) The product is not suitable for those with incomplete limbs, sensory or mental handicapped or lack of relevant experience(including children), except the situation that someone responsible for their safety guides and supervises them from side. 2) Take care of children and keep them from the product.

1. Application Environment

- (1) Please do not use or store the machine in damp environment, so as to avoid mildewing, electric shock, fire or mechanical breakdown.
- (2) Please do not use the machine when the room temperature is above 40 degrees Celsius.
- (3) Please do not use this machine outdoors.
- (4) Please do not put the machine in some places where there is too much dirt, oil or oxygen deficiency.
- (5) Please do not put the machine in heating furnaces, hot stoves or some place where the sun can shine directly, which will cause the overheating machine parts in the massage chair and cause a fire.
- (6) Please do not use the machine in an uneven place. The stented segment should be placed in a flat area.
- (7) To prevent electric shock, please install the earth wire. Please consult the sales shop when installing.
- (8) Please don't use the machine when smoking.



Type 4 Massage Chair's Hand-control Keys(Please check in accordance with the product).

Weaker: If the round rotary button twists in this direction, the velocity of vibration will slow down. If you twists it to the bottom, it will be closed down when you hear a clicking sound.

Stronger: If the round rotary button twists in this direction, the velocity of vibration will speed up.

Neck kneading: Stop the middle button, if you push the button up, the machine will keep clockwise rotation; if you push the button down, the machine will keep counterclockwise rotation.

Back kneading: Stop the middle button, if you push the button up, the machine will keep clockwise rotation; if you push the button down, the machine will keep counterclockwise rotation.

Manual Operation of Lying and Leaning on



Please sit down on the chair.



Hold the brakes with your left hand, put your right hand on the handrail, and people can sit back. The right hand exerting force to increase gravity, and the back naturally leaning backward.



Some people who cannot message the neck when massaging the back can move the body upwards.



After the messaging, you should sit up, hold the brakes on your left hand, and the barometer will restore the seat to its original state. If the product is the type of Two-charming-legs, the supporting legs should be recovered first and then reset.

The Instaling of Mantle



There are two veicros on the back of the massage chair. The top one is to stick mantle, while the below one is to stick head airbag or pillow.



First you should stick the bigger mantle, and then stick the smaller mantle or pillow or head airbag.




After finish sticking the bigger mantle, the afterbody of mantle is not placed on the cushion, and should be put at the back.




The smaller mantle is stick at the back of the bigger one, which is not put on the cushion. There is on mantle which can stick pillow or head airbag directly.

Preparation for Massaging




1. The Installing of Backrest

Raise your backrest up and turn it backwards. It has been fixed when you hear a clicking sound.



2. The Folding Method of Backrest

Press down and fix the hook. At the same time, slowly push forward the backrest.




3. The Movement of Message Chair

Notice! No manned movement. Do not move with small pulley on the easily damaged floor.

The Placement of Massage Chairs

1. The place where you put the message chair should have enough space to tilt the backrest and lift the tripod.
2. Ensure that the back part of the massage chair is at least 80 centimeters and has a space of 50 centimeters in front.
3. Ensure that there is no obstacle at the back and front part of message chair.
4. To prevent ground damage, place a blanket under the massage chair.



Day-to-day Maintenance

1. Keep clean and dust-free of the message chair, and do not put it in a damp environment.
2. If you don't use it for a long time, please cover it with cloth.
3. Please do not put the message chair in places where can be shined directly or heated, so as to avoid faded leather and machine aging.
4. Please close the master switch and pull out the power plug when cleaning.
5. Please do not use detergent containing organic solvents or benzene to clean the massage chair, so as to avoid faded leather, machine aging, machine breaking, etc.. Please use cleansing cream or maintenance wax to clean it.
6. If the mains cord have been broken, you should change it with special flexible wire or personal module.

Technical Parameters

Product name: Microcomputer Multifunctional Massage Chair

Rated voltage: 220V

Rated frequency: 50Hz